

UTBYTESVENTIL U2 TILL NORDIC 390-SERIEN (1993-2002). SKANDIC (1996-2003)

REPLACEMENT VALVE U2 FOR THE NORDIC 390 SERIES (1993-2002). SKANDIC (1996-2003)

VAIHTOVENTTIILI NORDIC 390-SARJAAN (1993-2002). SKANDIC (1996-2003)

ERSTATNINGSVENTIL FOR NORDIC 390-SERIEN (1993-2002). SKANDIC (1996-2003)


ERSTATNINGSVENTIL FOR NORDIC 390-SERIEN (1993-2002). SKANDIC (1996-2003)




ASENDUSVENTIIL NORDIC 390 SEERIALE (1993-2002). SKANDIC (1996-2003)

NULEIDIMO MECHANIZMO KEITIMO NOMAINAS VENTILIS NORDIC 390 SERIJAI (1993-2002). SKANDIC (1996-2003)



MECHANIZMO KEITIMO ADAPTERIS NORDIC SERIJOS KLOZETAMS (1993-2002)

Замена сливного механизма серии Нордик 390 (1993-2002)











→ NEXT PAGE










→ NEXT PAGE








→ NEXT PAGE




→ NEXT PAGE




Factory settings / Fabriksinställningar










A



B





RESERVDLAR.
RESERVEDELER.
RESERVEDELE.
VARAOSAT.
SPARE PARTS.
VARUOSAD.
ATSARGINĖS DALYS.
REZERVES DAĻAS.
ЗАПАСНЫЕ ЧАСТИ.



DRIFT & SKÖTSEL
DRIFT OG VEDLIGEHOJDELSE
DRIFT OG VEDLIKEHOLD
ASENNUS-, KÄYTTÖ- JA HOITO-OHJEET
ASSEMBLY AND MAINTENANCE
PAIGALDAMINE & HOOLDAMINE
MONTAŽA UN KOPSANA
MONTAVIMAS IR PRIEŽIURA
УСТАНОВКА И УХОД



A MEMBER OF THE
VILLEROY & BOCH GROUP

Sweden
www.gustavsberg.com/se/

Denmark
www.gustavsberg.com/dk/

Norway
www.gustavsberg.com/no/

Suomi/Finland
www.gustavsberg.com/fi/

Estonia
www.gustavsberg.com/ee/

Latvia
www.gustavsberg.com/lv/

Lithuania
www.gustavsberg.com/lt/

Україна
www.gustavsberg.com/ua/

Россия
www.gustavsberg.com/ru/